

.....Instruction Addendum.....

Walk Behind Spreader

After assembling the walk behind spreader, install the included locking collar onto the end of the lower linkage that protrudes through the linkage plate assembly (as shown). Once in place, tighten the set screw to lock the collar in place.

