

3014199 CONTROLLER CODES

System Status	Auger LED	Spinner LED	Vibrator switch	NOTE
1 Auger and Spinner EEPROM current calibration value out of the specification	-	-	NOT AFFECTED	Internal error, REPLACE CONTROLLER
2 Auger EEPROM current calibration value out of the specification	E	SHOWS SPEED	NOT AFFECTED	Internal error, REPLACE CONTROLLER
3 Spinner EEPROM current calibration value out of the specification	SHOWS SPEED	E	NOT AFFECTED	Internal error, REPLACE CONTROLLER
4 Auger and Spinner EEPROM current calibration value out of the specification	E	E	NOT AFFECTED	Internal error, REPLACE CONTROLLER
5 Auger fuse OFF	F	DARK	NOT AFFECTED	Please be sure that both fuses are in holders and both are OK REPLACE FUSE
6 Spinner fuse OFF	DARK	F	NOT AFFECTED	Please be sure that both fuses are in holders and both are OK REPLACE FUSE
7 Vibrator fuse OFF	SHOWS SPEED	SHOWS SPEED	BLINKS	Please be sure that both fuses are in holders and both are OK REPLACE FUSE
8 Spinner motor disconnected	S	P	NOT AFFECTED	Spinner is disconnected
9 Auger motor disconnected	A	A	NOT AFFECTED	Auger is disconnected
10 Vibrator motor disconnected	U	U	NOT AFFECTED	Vibrator is disconnected
11 Low voltage applied to the system	L	O	NOT AFFECTED	Check voltage, increase supply voltage
12 Internal communication problem	-	-	NOT AFFECTED	Internal error, REPLACE CONTROLLER
13 Auger was overload and auger load was disconnected.	BLINKS	SHOWS SPEED	NOT AFFECTED	Turn power OFF to reset the error.
14 Spinner was overload and spinner load was disconnected.	SHOWS SPEED	BLINKS	NOT AFFECTED	Turn power OFF to reset the error.